

AC SCHNITZER

-Installation in- structions

**Emblem on the side
R12nineT / R12**



S700781-F22

General information!



AC Schnitzer emblem on the side

Important notes !

These installation instructions must be read in full before starting the installation work and do not claim to be completeness with regard to each work step. Subject to technical, editorial and content changes! AC Schnitzer accepts no liability for damage caused by incorrect installation!

The goods must
be checked for completeness and intactness
before starting work.
Later complaints cannot be considered.

These installation instructions are intended exclusively for use by authorised AC Schnitzer or BMW dealers. The target group for these installation instructions is in all cases specialist personnel trained on BMW vehicles with the appropriate expertise and tools. Knowledge of material properties and standards is assumed!

Before mounting:

Before mounting, the vehicle must be adequately secured against rolling away or tipping over. The use of the original BMW assembly stand is recommended for this purpose!
All work must be carried out in accordance with the applicable safety regulations (e.g. safety goggles).

After assembly:

A test ride must be carried out after all work has been completed! After completing the test ride, all screw connections must be checked for tightness and all moving parts must be checked for sufficient clearance.

As the manufacturer, we are obliged to point out that any modifications you make to a vehicle authorised for public traffic require approval by a test centre and registration in the vehicle documents! As the legal regulations may vary from country to country, please enquire with the relevant authorities.

Installation time (1 AW = 5 minutes)

The installation time is **2 AW**.

Tools required:

- Torx screwdriver

Assembly instructions no.: S700781-F22 / Version: 18/09/2024 / TSch

AC Schnitzer - automotive technology - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -130

Components supplied

**AC
SCHNITZER**

AC Schnitzer emblem on the side



1 set

A = AC Schnitzeremblem on right side

B = AC Schnitzer emblem on left side

Assembly instructions no.: S700781-F22 / Version: 18/09/2024 / TSch

AC Schnitzer - automotive technology - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -130

Assembly instructions

**AC
SCHNITZER**

AC Schnitzer emblem on the side

Assembly

Fig. 1

Loosen the original fastening screws of the emblem R12 with a suitable Torx screwdriver and remove the emblem.



Fig. 2

Position AC Schnitzer emblem and tighten with the standard fixing screws. Use threadlocker.



Subject to errors, alterations and technical developments

!

Assembly instructions no.: S700781-F22 / Version: 18/09/2024 / TSch

AC Schnitzer - automotive technology - Neuenhofstraße 160 - D - 52078 Aachen - Tel. 0241/5688 -130