## 22mm hexagonal



In order to fit and remove the front wheel of your R 1200 GS you'll need our 22mm hexagonal bolt made of high-quality stainless steel (no. SW22VA) and one of the two flat wrenches: Combination wrench, made of chrome vanadium steel Adjustable flat wrench, polished head, max. span width 25 mm In order to fit and remove the handlebar of your R1200GS you will need the Torx E10 for 1/2 or 1/4 drive made of high-quality chrome vanadium steel.

R1200GS 2004-2012	
R1200GS Adventure 2005-2013	
HP2 Enduro	
HP2 Megamoto	
Art-Nr.: SW22VA	6,30 EUR
22mm hexagonal bolt	
Art-Nr.: 823522	7,00 EUR
Combination wrench 22/22	
Art-Nr.: 2408	21,50 EUR
Adjustable flat wrench	