

## Inside bags for Trekker top cases



These bags help you to load and unload your motorcycle cases. Small parts or papers can be carried in the pocket on the outer side of the bag and the chord helps you to carry the bag. Water-repellent material.

Art-Nr.: 7687611

58,90 EUR

Inside bag for 30L Trekker Dolomiti top case

Art-Nr.: 8543194

51,90 EUR

Inside bag for 46L Trekker Dolomiti top case / 42L Trekker Outback top case

### Additional pictures:



7687611



7687611

